

Pop-Up Shade

Protect and Shade Your LCD



Clearly View Your Screen in Sunlight

Protects Your Screen from Damage

Attaches Easily to Your Camera

Pop-up Shade

Pop-Up Shades are protective covers for LCD screens which also double as glare guards. These sturdy and lightweight covers are easily installed (and removed), but most importantly help to protect a digital camera's expensive LCD screen. When flipped up, the shade provides easier viewing of the display in bright sunlight.

Snap-On PRO Pop-Up Shades



The digital SLR professional is designed to attach to your camera using the existing eye piece and slots around the display. It easily snaps on and off and features an optically clear plastic cover to protect your camera's screen. The simple pop-up design allows for easy opening to block glare. Buttons on the professional shades are aligned with your camera to reduce the wear and tear on delicate parts and components. The two-part design enables easy removal of the shade while keeping the clear plastic in place for protection.



Snap-On Standard Pop-Up Shades

The digital SLR standard simply snaps on the back of most popular digital SLR camera models. Optically clear plastic covers your camera's screen, leaving less chance of scratching or breaking your display. The simple design of the shade allows for easy opening to block glare from bright light.



Universal and Point & Shoot Pop-Up Shades

The Universal Pop-Up Shade is designed to fit hundreds of cameras, both new and old. The Universal shade attaches to your camera with a residue free adhesive. Optically clear plastic protects your camera's screen and the simple design allows for easy opening to block glare. The two part design allows for easy removal of the shade while keeping the clear plastic in place for protection. This shade is perfect for those with a point and shoot camera. Available in black and silver, sizes: 1.6", 1.8", 2.0", 2.5", 2.7/2.8" and 3.0"

